

If you want let driver into WIFI certification testing mode, you can do as the following instruction. The WIFI certification testing mode is only for WIFI certification.

**Adding the “wifi\_test=1” parameter when inserting driver module.**

```
$> insmod 8712u.ko wifi_test=1
```

**or**

```
$> insmod 8712u.ko wifi_test=1
```

Realtek